COMPONENTS	Actions to be taken	FREQUENCY
DOSER	Complete emptying, opening of the trapdoors and rotation of the axles	Daily
DOSER	De-seizing / Lubrication of metering box rings	Once per sowing campaign
CHUTES	Condition of the pipes: no cuts	Once per sowing campaign
CHUTES (WEAR)	Check wear parts • Shoe • Double discs (change if ø < 30 cm) • Disc scraper: adjustment or change	Daily
CHUTES (SETTING)	 Identical fertilization line – furrow distances (5 to 7 cm) Same planting depths Check the fertilizer flow on each row (tolerance of 10% maximum difference) 	Before each sowing campaign
CHUTES	 Check the lengths of the hoses and the absence of elbows Checking cyclones: checking cleanliness 	Once per sowing campaign