| COMPONENTS | Actions to be taken | FREQUENCY |
|--------------|---|-----------------------------------|
| DOSER | Complete emptying and blowing with compressed air (no water or oil). Opening the trapdoors and rotating the shafts | Daily |
| DOSER | De-seizing / Lubrication of metering box rings | Once per sowing campaign |
| HOSES | Check their condition, tightness and lengths (no cracks or bends) | Before each sowing campaign |
| CHUTES | Depending on the products used, check the presence of the appropriate diffusers Check their position | Before each sowing campaign |
| DISTRIBUTION | Flow control on each row: tolerate a maximum deviation of 10% | Before each sowing campaign |